

Lineset Schedule

Luhrs Performing Arts Center Shippensburg Pennsylvania

Lineset #	Location	Use	Trim	Notes
PL	0'-0"	Plaster Line		
0	0'-6"	Fire Curtain		Permanent
1	1'-7"	Proscenium Header		Permanent
2	2'-5"	House Curtain		Permanent
3	3'-0"	Border # 1		
4	3'-6"			
5	4'-0"	Leg # 1		
6	4'-6"			
7	5'-0"	1st Electric		
9	6'-0"	Concert Ceiling		Permanent
11	7'-0"			
12	7'-6"			
14	8'-6"			
15	9'-0"			
16	9'-6"	Border # 2		
17	10'-0"	Leg # 2		
18	10'-6"			
19	11'-0"			
20	11'-6"			
21	12'-0"			
22		Tab DSR		Permanent, lineset runs perpendicular to proscenium
23	13'-0"	Concert Ceiling		Permanent
24		Tab DSL		Permanent, lineset runs perpendicular to proscenium
25	14'-0"			
26	14'-6"	Border # 3		
27	15'-0"	Legs # 3		
28	15'-6"	Black Traveler		Prefer to not move this traveler
30	16'-6"	Movie Screen		
32	17'-6"			
34	18'-6"			
35	19'-0"			
36		Tab USR		Permanent, lineset runs perpendicular to proscenium
37	20'-0"	Concert Ceiling		Permanent
38		Tab USL		Permanent, lineset runs perpendicular to proscenium
39	21'-0"	Border # 4		
40	21'-6"	Legs # 4		
41	22'-0"			
42	22'-6"			
43	23'-0"			
44	23'-6"			
46	24'-6"			
47	25'-0"			
49	26'-0"	Border # 5		
50	26'-6"			
52	27'-6"			
54	28'-6"			
56	29'-6"	Legs # 5		
58	30'-6"	Black Scrim		
60	31'-6"	CYC Lights		
62	32'-6"			
63	33'-0"			
64	33'-6"			
65	34'-0"	Border		
66	34'-6"			
67	35'-0"	Cyc		
68	35'-6"	Full Stage Black		